



User Manual

Continuous Wave Single Frequency Lasers

Blue Note[®] Series

488nm 100mW

Copyright 2012, KLASTECH GmbH. All rights reserved.

Information presented herein is believed to be accurate and reliable. No responsibility is assumed for its use, neither for any infringements of the rights of others. KLASTECH reserves the right to introduce changes to the product specifications, design, etc., at any time without advance notice.

Revision: March, 2013

**Before starting the laser:
for thermal equalisation keep it at least 2 hours
under the intended operation environment.**

Do NOT operate the laser without connecting the external fan!

Contents

Introduction	4
General Description.....	4
Compliance.....	4
Safety.....	4
System Completeness, Unpacking and Handling	5
Setting-up and Operation of the BLUE NOTE [®] Laser	6
Maintenance and Service	8
Warranty.....	8

Introduction

This user's operation manual describes safety regulations, compliance status, damage prevention considerations, operating characteristics and other practical information. Operation of the BLUE NOTE[®] laser outside the guide lines described in this manual carry risk of damage to the product and possible safety hazard to the operator.

The operator should read and understand this manual prior to using the laser.

This manual refers to KLASTECH lasers for BLUE NOTE[®] series within range of output powers up to 100 mW.

General Description

The BLUE NOTE[®] laser by KLASTECH is a complete, easy to operate, turn-key laser system that emits single frequency TEM₀₀ beam of a preset power at 488nm. The laser design exploits the new technology which inherently features single frequency operation.

Compliance

The laser complies with international regulation IEC 60825-1 and hence with the corresponding national versions (e.g. Germany: DIN EN 60825-1).

Safety

When installing and using the BLUE NOTE[®] laser, the following safe operating procedures are to be observed:

- Enclose the path of the laser beams whenever possible.
- Never look directly into the laser beam or any reflections of the laser beam as possible eye damage may result. **Avoid eye or skin exposure to direct or scattered radiation!**
- Always wear appropriate protective laser goggles.
The goggles must comply with this specifications: 488nm, D:L6, IL6, R:L6, OD6.0+
- Avoid setting up the laser with the beam position at eye level.
- Block the path of the laser beam with a "Beam Trap" if the beam is directed toward the area where people can be located.
- Use "Interlock" facility of the laser controller to switch off the laser in cases of unexpected access to the laser working location.
- **Do Not** attempt to open the laser head or laser controller. Doing so may expose the user to possible radiation or electrical voltage hazard.

Warning labels located on top of the laser head:



System Completeness, Unpacking and Handling

The BLUE NOTE[®] laser package comprises of:

- BLUE NOTE[®] laser head
- Laser controller 04_01_01
- Connecting cables
- Interlock connector
- Numbered switch keys (set of 2)
- Operation manual (this document) with performance test certificate
- 12 Volt AC/DC converter
- AC/DC converter for the external fan

Before unpacking visually check the carton box for damage. Make sure that the shock and temperature sensors attached to the box do not indicate any records outside the parameter range allowed during delivery/storage. Advise KLASTECH of any box damage or sensor records. If there is no visible damage or ‘out-of-range’ - sensor records, remove packed items from the carton and visually inspect them for damage separately. Especially, handle the laser head carefully to prevent undesirable mechanical shock.

Note: Laser head and controller are tuned to each other to form a self-compatible set. They are labelled accordingly with reference to the serial number of the respective counterpart. The laser head must not be used with other than the specified controller! Mismatching will probably result in damage of the laser head!



Pic. 1: Sticker located on the laser head and the controller indicating the serial number of the laser and the serial number of the controller.

Setting-up and Operation of the BLUE NOTE[®] Laser

Note: Before starting the laser, for thermal equalisation keep it at least 2 hours under the intended operation environment.

Position the laser controller 04_01_01 in an appropriate location within the range of the connecting cable length (up to 1.75m).

Use the interlock connector plugged into the laser controller back panel (right socket).

Connect the laser head and laser controller with the connecting cable. Use the M2.5 screws for fastening both ends of the cable within corresponding sockets.

Plug 12 Volt AC/DC converter output into power socket on back panel of the laser controller (left socket).

Plug the 12 Volt AC/DC converter output into the connector attached to the external fan.

Put the switch key into the lock on the front panel of the laser controller. The initial switch key position is “OFF”.

Plug both AC/DC converters into the mains.

Turn the key switch to position I. The “Power” and “Warm-up” LED indicators are illuminated. After the warm-up delay time the “Warm-up” indicator will extinguish and “Standby” will illuminate.

Note: Should the switch be turned to the ON position before the standby indicator has illuminated the system will reset to wait for the switch to be turned to standby. Switching to standby will start the warm up period again.

Open the mechanical shutter in front of the output window. Therefore push the shutter upwards.





Turn the key switch to position II. This operation switches on the pump diode inside the laser head. The “Emitting” LED is illuminated and laser light is emitted. The LED “Stable” is illuminated as soon as the output power is stabilized.

To switch off the laser, turn the key switch to position I or off.

Note: The switch key can only be removed in the off position.

Note: Controller and laser head must be placed in the field of view of the operator, so that the operator is able see and reach the control panel at all times.

2x ISO 4762 - M6 x 14



ALLE ANGABEN IN [mm]	
√ Rz 6,3	√ 0,1
ALGEMEINTEILNORMEN	ISO 2768 - FH
BEZ.:	13.05.12 IK
GEPR.:	
PROD.:	
DATUM	NAME

KLASTECH GmbH
Friedenstraße 41-43, D-44 139 DORTMUND

DAS URRECHT DIESER ARBEIT LIEGT BEI KLASTECH-KARPUHKO LASER TECHNOLOGIES GMBH. DIESES DOKUMENT IST VER-
TRAULICH UND AUSBLIEBICH FÜR DEN ZWECK, ZU DEM ES ERSTELLT WORDEN IST. JEGLICHE WEITERGABE, REPRODUKTION UND
VERWERTUNG DIESER DOKUMENTS ODER VON TEILEN DAVON IST NUR MIT SCHRIFTLICHEM EINVERSTÄNDNIS DER
KLASTECH-KARPUHKO LASER TECHNOLOGIES GMBH GESTATTET UND DIESER VERWEK MUS IN JEDEM REPRODUKTIONSHI-
GECHLOSSEIT SEIN.
THE COPYRIGHT IN THIS WORK IS VESTED IN KLASTECH-KARPUHKO LASER TECHNOLOGIES GMBH AND THE DOCUMENT IS ISSUED
IN CONFIDENCE FOR THE PURPOSE ONLY FOR WHICH IT IS SUPPLIED. IT MUST NOT BE REPRODUCED IN WHOLE OR IN PART OR
USED FOR TENDERING OR MANUFACTURING PURPOSES EXCEPT UNDER AGREEMENT OR WITH THE CONSENT IN WRITING OF
KLASTECH-KARPUHKO LASER TECHNOLOGIES GMBH AND THEN ONLY ON THE CONDITION THAT THE NOTICE IS INCLUDED IN
ANY SUCH REPRODUCTION.

BEZEICHNUNG: Blue_Laser_University_Style

ZEICHNUNGSNUMMER: 01_01_0003

A4

MAßSTAB: 3 : 1
BLATT 1 von 1

Maintenance and Service

With use, the output window in the front of the laser head may become dirty or dusty. Should this happen the quality of the output beam can be sacrificed. In such a case the output window can be cleaned provided certain precautions are observed:

- Make sure the laser is turned off and disconnected from the power source.
- Carefully clean the outside surface of the window, using an appropriate soft laser optics cleaning material lightly moistened with alcohol (methanol).
- Do not attempt to clean the window while the laser is operating.
- As the laser head is filled with Nitrogen and sealed, **do not** attempt to open the laser head, also for safety hazard reason as explained above.

There are no other maintenance procedures for the user of the laser. All maintenance and service must be performed at KLASTECH manufacturing facilities.

A service manual is not provided because the product is not intended to be serviced by dealers or distributors.

Warranty

KLASTECH's BLUE NOTE[®] lasers are warranted to be free from defects in materials and workmanship. KLASTECH does not warrant the system applicability for any intended purpose. KLASTECH disclaims and excludes all other warranties, particularly implied warranties of non-infringement and merchantability. In no event will KLASTECH be liable for an indirect, incidental, special or consequential damages, including but not limited to loss of anticipated profits or benefits. In no case will KLASTECH's aggregate liability to buyer be greater than the purchase price paid by the buyer to KLASTECH for the products which are the subject of buyer's claim.

The warranty period is 12 months except for the pump diode. Warranty for the pump diode is 12 month but limited to 3,000 hours of operation. Sub-systems manufactured by others but integrated by KLASTECH into the laser system are covered by the original manufacturer's warranty.

In case of valid warranty claims KLASTECH liability is, according to our choice, limited to repairing or replacing the product at KLASTECH's or buyer's location.

A warranty claim must be made within the warranty period, promptly after the fault is detected. To be valid, the warranty claim has to include the product serial number, the date of shipment and a detailed description of what the buyer regards as failure.

Before returning any products the buyer has to contact KLASTECH for written authorization and instructions on returning procedure and shipment. Return of any goods have to be done prepaid and are at the risk of the buyer. In case the claim is accepted as valid warranty claim KLASTECH will refund costs of transportation to buyer.

In case of invalid warranty claims KLASTECH is allowed to charge for service cost and return the product to the buyer's expenses.

KLASTECH-GmbH
Friedenstr. 41-43
44139 Dortmund, Germany
www.klastech.com